

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE


DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES



spatouch™ 4/4+

USER GUIDE

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES


YOUR SPA TOUCH™ 4/4 +

TOUCH TO START

Your Spa Touch 4 (4.03" L x 5.73" W x .52" D) and Spa Touch 4+ (4.71" L x 7.27" W x .65" D) display by touching anywhere on the screen. Use your fingertip to touch, scroll, slide or swipe to activate the various icons and images on the panel screen.


When you power up, you will see a "splash" screen, and then a simple at-a-glance temperature and time status.

NOTE: All features and functions available are shown here. Your system display may vary.



NAVIGATING HOME

The Spa Touch 4/4+ Home screen is your central connection to all your panel offers.



Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION


- Reminders, Warnings, Errors

FCC AND NOTICES


YOUR SPA TOUCH 4/4 + (CONT'D)

PANEL FEATURES AND FUNCTIONALITY

All features and functions available are shown here. Your system display may vary.



RELAX MODE



Touch to turn off all features

Touch to go to Home Screen

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES

PREPARE YOUR SPA

NOTE: All features and functions available are shown here. Your system settings display may vary.


BEFORE YOU SOAK

IMPORTANT: Your spa requires essential settings to provide optimal performance.


Follow these steps to prepare your spa for first use:

- 1 "Prime The Pump" on page 5.
- 2 "Connect your Spa Touch 4/4 +" on page 6.
- 3 "Update Software" on page 9.
- 4 "Set The Time" on page 10.
- 5 "Set Filter Cycles" on page 11.
- 6 "Adjust Water Temperature" on page 12.
- 7 "Turn On The Jets" on page 14.

Find all settings from the Home Screen > **Settings** ⚙️.



Home Screen



Settings Menu

After you complete these essential settings, customize your preferences to suit your schedule, and have your spa ready and waiting for your enjoyment.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES


PRIME THE PUMP

Turn each jet on and then off to see that air bubbles are purged. Priming is performed with initial use, and helps to clear waterflow of trapped air or possible stoppage that can strain the system.

To prime the pump:

- 1 Power up the Spa Touch 4/4+ during initial use to activate the pump priming mode.

The message to prime your spa displays.



Priming Message

- 2 Touch each jet on and then off to see that air bubbles are purged.

The jets start up and clear air bubbles from the pipes.

NOTE: During priming, you can manually override, and touch other features lit on the panel. (lights, misters, blower, etc.). Components and features display dimmed cannot be controlled by your panel.

NOTE: At minimum, you will always see one pump active for continuous water flow, and filtration through the system.

After priming, the spa screen displays active features your panel controls.

Find Help

YOUR SPA TOUCH 4/4 +

Touch To Start
Navigating Home
Panel Features and Functionality

PREPARE YOUR SPA

Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

Connect Wi-Fi
Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

Spa Information

COMMUNICATION

Reminders, Warnings, Errors

FCC AND NOTICES

CONNECT YOUR SPA TOUCH 4/4 +


IMPORTANT: Connecting your Spa Touch 4/4+ to your Wi-Fi delivers timely updates your system needs for ongoing improvements.

BEFORE YOU BEGIN: Have your Wi-Fi network and password available.

CONNECT WI-FI


To connect to Wi-Fi:

- 1 From Home, touch **Settings**, and then scroll and touch **Wi-Fi**. The Wi-Fi Screen displays "Not Connected" with available networks.




Settings Menu

- 2 Touch to connect your spa panel to your Wi-Fi network.



Wi-Fi Screen

A keyboard displays for you to type your network password.



Enter Password Screen

- 3 Enter your network password and touch **Save**. "Attempting to connect..." displays, and upon connection, the Wi-Fi screen displays with your newly selected network.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES

CONNECT YOUR SPA TOUCH 4/4 + (CONT'D)


4 Touch **Back** < to return to the Settings Menu.

REGISTER YOUR SPA TOUCH 4/4+

NOTE: This step is needed to establish your ControlMySpa (CMS) account, and give you access to use the CMS App from your mobile device. You will need your 8-digit CMS Code from your spa dealer.


To register your Spa Touch 4/4+:

5 From the Settings Menu, touch **ControlMySpa**.




Settings Menu

The ControlMySpa information screen displays.



6 Touch the Edit icon , and the ControlMySpa keyboard displays.



Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

CONNECT YOUR SPA TOUCH 4/4 + (CONT'D)

- 7 Enter the CMS Code supplied by your spa dealer, and then touch **Save**.

The ControlMySpa screen displays a QR code you will use to pair your spa when you establish your **ControlMySpa** App account.

Leave the ControlMySpa screen open on your panel to complete **Spa Account Setup**.



ControlMySpa Screen

Create a ControlMySpa Account

- 8 Using your mobile phone, go to your App store, and download "ControlMySpa."
- 9 Follow the in-app prompts to set up an account, and then **Setup Spa**. Be sure to set up your spa account "by QR code."
- 10 Use your phone's camera to scan the QR code displayed on the Spa Touch 4/4+ panel, and complete **Spa Account Setup**.



- 11 **IMPORTANT:** When you see "Account Setup Successful", check your email to authenticate your account and complete this step.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

UPDATE SOFTWARE

IMPORTANT: Be sure to update software for your Spa Touch 4/4+, and keep your system current.

To check for software updates:


- 1 From Home, touch **Settings** ⚙, then **Software Update**.



Settings Menu


The Software Update Screen displays.

- 2 Touch **Update**.



Settings Menu

The Status displays "Getting Updates", "Downloading", "Installing", and "Current" when the update is complete.



Software Update Screen

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

SET THE TIME

The time you set displays on the Home Screen, and becomes your system's time, used to automate the duration of other functions, such as filter cycles, activation and water maintenance for reliable performance. **IMPORTANT: An iMessage, ⓘ, displays when the time needs to be set, and turns off after you set the time.**


To set the time:

- 1 From the Home screen, touch **Settings** ⚙️, then **Time**. The Time Screen displays.



Settings Menu

- 2 Touch and scroll to the current time and **Save**.



Time Screen

The new time is saved in the system.

Find Help

YOUR SPA TOUCH 4/4 +

Touch To Start
Navigating Home
Panel Features and Functionality

PREPARE YOUR SPA

Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

Connect Wi-Fi
Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

Spa Information

COMMUNICATION

Reminders, Warnings, Errors


FCC AND NOTICES

SET FILTER CYCLES

Daily filtration assures your spa is operating as designed, and the water is clean and ready to enjoy.

To set the filter cycle times:

- 1 From the Home Screen, touch **Settings** ⚙, then **Filter Cycles**.



Filter Cycles

The Filter Cycles Screen displays the number of cycles you can schedule.

- 2 Touch **Filter Cycle 1**.



Filter Cycles

- 3 Touch **Start** and touch arrows to set the filter cycle starting time. Your desired filter cycle duration adjusts as you make changes.
- 4 Touch **End** and touch arrows to set the filter cycle ending time. Your desired filter cycle duration adjusts as you change it.
- 5 Touch **Save**. The Filter Cycles screen displays.
- 6 Repeat steps to set additional filter cycles displayed.
- 7 Touch **Back** < to return to the Home Screen.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES


ADJUST WATER TEMPERATURE

Find your current water temperature displayed in large numbers on the Water Temperature reading of the Home screen.

Note: *Temperature range is determined by the high and low range available in your system. Below represents a high range. Your system may vary. See "Temperature Range" on page 17 for more information.*

To set the desired water temperature:

- 1 From the Home Screen, touch the **Water Temperature** area of the screen.



Home Screen

The Desired Temperature screen displays.



Desired Temperature Screen

Higher

- 2 Touch the **plus** + and **minus** — signs or slide the bar along the bottom of the screen for your desired temperature.
NOTE: *As the system changes the temperature, the panel reading displays in color.*
- 3 Touch the unit of measure, upper right, and touch Fahrenheit (°F) or Celsius (°C) and change how the water temperature unit of measure is displayed.
The system begins to adjust to the newly set temperature.
- 4 Touch **Back** < to return to the Home Screen.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

SPA HOLD

Use this setting for temporary servicing or maintenance. When started, it pauses all spa activities for 1 hour.


To start Spa Hold:

- 1 From the Home Screen, touch **Settings** ⚙️.



Home Screen


The Settings Menu displays.



Settings Menu

- 2 Scroll and touch **Spa Hold**.


The Spa Hold Screen displays.



Start Hold

- 3 Touch **Start Hold**

The Spa pauses displaying the minutes remaining.



- 4 You can end the Hold by touching **Exit**.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

TURN ON THE JETS

Turning on the jets provide the water pressure and motion for an enhanced, therapeutic soak.

To turn on the jets:


- 1 From the Home Screen, touch the available **Jet**  to activate, and touch the arrow  to see more features.



Home Screen

The Spa Features display with additional components connected to your system.

- 2 Touch on each lit jet for as many jets you want to activate.



Spa Features

- 3 Touch the arrow  to display the Home Screen.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

ADJUST SCREEN BRIGHTNESS

Adjust your panel display brightness.

To change the display brightness:


- 1 From the Home Screen, **Settings** ⚙️, touch **Panel Settings**.



Panel Settings

The Screen Brightness setting displays with the Brightness Slider along the screen bottom.

- 2 Touch the **plus** + and **minus** — signs or slide the bar on the screen to adjust your desired level of brightness.



Screen Brightness

- 3 Touch **Home** 🏠 to return to the Home Screen.

Find Help

YOUR SPA TOUCH 4/4 +

Touch To Start
Navigating Home
Panel Features and Functionality

PREPARE YOUR SPA

Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

Connect Wi-Fi
Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

Spa Information

COMMUNICATION

Reminders, Warnings, Errors

FCC AND NOTICES


SET THE HEAT MODE

NOTE: All features and functions available are shown here. Your system display may vary.

Keep your spa heated with these options: Run the spa continuously, as Ready (R) state or Rest state (IR) for energy efficiency.

To change the heat mode:

- 1 From the Home Screen, touch **Settings** ⚙, then Heat Mode. The Heat Mode Screen displays.



Home Screen

- 2 Touch to change the Heat Mode.



Heat Mode

Options are:

Ready - regulates temperature continuously, and best for frequent, scheduled use.

Rest - regulates temperature only during filter cycles.

Ready-In-Rest - When your spa is in Rest Mode, and you touch **Jet 1** 🌊, the system switches to Ready-In-Rest Mode and heats the water to the desired temperature for one hour. Then, the spa returns to Rest Mode.

NOTE: To cancel Ready-In-Rest and return back to Rest Mode within the hour, perform step 2 and select Ready setting.

- 3 Touch **Home** 🏠 to return to the Home Screen.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES

SET THE HEAT MODE (CONT'D)


TEMPERATURE RANGE

Choose a range for your Desired Temperature setting, and that becomes the range you use to heat or cool the spa water. For example, choosing **High** may display a range from 80° F as the lowest degree, and 104° F as the highest of the High range.

NOTE: Your system's available ranges will vary.

To change the range between High and Low:

- 1 From the Home Screen touch **Settings** ⚙, then **Temperature Range**.



Settings Menu

The Temperature Range Screen displays.



Temperature Range

- 2 Touch either **High** or **Low** to choose what range displays in the Desired Temperature screen.
Your selected range displays as the limits of your Desired Temperature screen.
- 3 Touch **Home** 🏠 to return to the Home Screen.

Find Help

YOUR SPA TOUCH 4/4 +

Touch To Start
Navigating Home
Panel Features and Functionality

PREPARE YOUR SPA

Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

Connect Wi-Fi
Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

Spa Information

COMMUNICATION

Reminders, Warnings, Errors


FCC AND NOTICES

SET LOCKS

Restrict panel access and changes to water temperature setting by setting the locks.

To change the security setting:


- 1 From the Home Screen, touch **Settings**  and scroll to touch **Locks**.



Settings Menu

The Locks Screen displays two types of locks you can set:

- Settings Lock - This lock restricts access to controls, including water temperature and scheduled maintenance functions, in order to maintain spa water quality and safety of your spa guests.
- Panel Lock - This lock restricts preferential and personalize settings that affect the individual spa experience, including what is displayed on the panel and panel access to make changes to settings.



Locks Screen

- 2 Touch the off / on toggle. 
- 3 Touch the **Lock** icon. The selected lock displays locked / unlocked.
- 4 Repeat steps 2 and 3 to change the setting again.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors


FCC AND NOTICES

SET LANGUAGE

You can set a different language for the text in the panel screen display.

To set a different language:

- 1 From the Home Screen, touch **Settings**  and scroll to touch **Language**.



Settings Menu

The Language Menu displays.



Language Menu

- 2 Touch your desired language to use in the panel screens. Your selection is indicated in **blue** and the new language displays in the panel .
- 3 Touch **Back**  until the Home Screen displays in your selected language.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION

- Reminders, Warnings, Errors

FCC AND NOTICES


DIAGNOSTICS

Find your system settings and fault log record here.

To find your system Information:


- 1 From the Home Screen, touch **Settings** ⚙️, and scroll to touch **Diagnostics**.

The Diagnostics Menu displays access to two status pages:




Settings Menu

- 2 Touch **System Information** or **Fault Log** to see corresponding displays.



Diagnostics Menu

Your selected information displays.



System Information Example

SPA INFORMATION

To find your spa information:

- 1 From the Home Screen, touch the iMessage ⓘ .



The Spa Information screen displays.

Find Help

YOUR SPA TOUCH 4/4 +

- Touch To Start
- Navigating Home
- Panel Features and Functionality

PREPARE YOUR SPA

- Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

- Connect Wi-Fi
- Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

- Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

- Spa Information

COMMUNICATION


- Reminders, Warnings, Errors

FCC AND NOTICES


COMMUNICATION

REMINDERS, WARNINGS, ERRORS

Helpful messages display to alert you of conditions and status, as well as safe troubleshooting steps to maintain your spa. Messages display on the Home Screen, and throughout your system to keep you aware of important updates.



Sample Status Message



Sample Instruction Message

See [Control Panel Communication](#) at [Balboawater.com](#) for all messages.

Find Help

YOUR SPA TOUCH 4/4 +

Touch To Start
Navigating Home
Panel Features and Functionality

PREPARE YOUR SPA

Before You Soak

PRIME THE PUMP

CONNECT YOUR SPA TOUCH 4/4 +

Connect Wi-Fi
Register your Spa Touch 4/4+

UPDATE SOFTWARE

SET THE TIME

SET FILTER CYCLES

ADJUST WATER TEMPERATURE

SPA HOLD

TURN ON THE JETS

ADJUST SCREEN BRIGHTNESS

SET THE HEAT MODE

Temperature Range

SET LOCKS

SET LANGUAGE

DIAGNOSTICS

Spa Information

COMMUNICATION

Reminders, Warnings, Errors

FCC AND NOTICES

FCC AND NOTICES

RSS-Gen & RSS-247 statement:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

RSS-102 Statement:

This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement:

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

This controller is not intended for transportable pool use.



Contact a sales representative
United States - sales@balboawater.com
Europe - europe@balboawater.com

Balboa
2020 Piper Ranch Road
San Diego, CA 92154
Phone: 714.384.0384
www.balboawater.com
Specifications subject to change without notice.



PLEASE
VISIT US